

# Slip Stop Tapes & Treads

*Slip resistant self adhesive marking tape*



**"maintenance made easy"**



## PRODUCT DESCRIPTION

**The Polycote Slip Stop Marking Tapes, Treads and Aquasafe Tape provide an instant solution where a good level of slip resistance is required. They also come in a large range of colours.**

**TYPICAL USES** Walkways, warehouses, stairs, swimming pool areas (aquasafe tape), and other areas requiring good slip resistance.

**SUITABLE SUBSTRATES** The Polycote Slip Stop Marking Tapes can be applied to any smooth hard surface, such as concrete, tarmac, wood, bricks, epoxy coatings and many others.

**COLOUR** The Slip Stop Marking Tapes and PVC Treads come in a range of colours including, black, yellow, translucent, red, white, green, blue, and hazard. The Aquasafe tape is available in white, grey, black or translucent.

**PACKAGING** The Aquasafe tape and the Slip Stop Marking Tapes come in a range of 50, 100 or 150mm wide tapes and are supplied in 18.3m rolls. The PVC Treads are 150mm x 610mm.

## APPLICATION GUIDE

### SURFACE PREPARATION

A clean, dry surface is essential. It is important to ensure that all surface contaminant (paint flakes, oil, grease etc) are removed. DO NOT use methylated spirits/petrol/lighter fluid etc. as these leave behind a thin, greasy residue. Porous surfaces must be sealed with Polycote Slip Stop Primer prior to application to prevent water attacking the adhesive. Apply a thin coat to the cleaned surface using a paintbrush, then leave to dry.

## APP. GUIDE Cont.

### TAPE APPLICATION

Peel back part of the release liner then press the adhesive firmly onto the prepared surface, and slowly keep peeling back the liner while applying the tape. Try to ensure that the tape is not taut.

### FINISHING

Once applied, press tape down firmly using a even pressure (decorating rollers are excellent for this). We recommend sealing the edges using Polycote Slip Stop Edge Sealer as this will extend the life of the product. Only use a small amount down the edges, a thin bead. If correctly applied, the new surface can be walked on straight away, though you will get maximum benefit from the adhesive system after 48 hours.

### APP. TEMPERATURE

Ensure prepared surface is above 10°C.

### MATERIAL STORAGE

Ensure the material is kept in dry, warm conditions in the original protective packaging.

## ANY QUESTIONS?

Polycote Technical Helpline:  
**01234 846400**

All reasonable care has been taken in supplying the above information. However, any figures quoted do not constitute a specification but represent typical values obtained. It is the customer's responsibility to ensure for himself that the product is fit for the intended purpose & that conditions are suitable. Any technical advice is offered in good faith, but without warranty. This is also applicable when proprietary rights & third parties are involved. In the light of the Company's policy of continual research & development, it is the customer's responsibility to ensure that the information contained herein has not been superseded.

**REV: 06/17**

**Polycote UK**  
Centre Point • Wolseley Road • Woburn Road Industrial Estate  
Kempston • Beds • MK42 7EF  
Technical Help line: 01234 846400

